


Thermostat Wiring: 240V



NUHEAT

FOR SIGNATURE, HOME AND ELEMENT THERMOSTATS



RELAY SWITCH OR CONTACTOR FOR 240V

This switch allows you to control multiple circuits with a single control. It may be conveniently located inside an electrical junction box.

NVENT NUHEAT FLOOR HEATING CONTROL WITH G.F.C.I.

See diagram for wiring instructions.

WIRING INSTRUCTIONS FOR RELAY (240V)

- 0 – Line 1 (Black) from control
- 1 – Line 2 (Red) from control
- 2 – Line 1 (Red) from GFCI breaker
- 6 – Line 2 (Black) from GFCI breaker
- 4 – Line 1 (Red) to nVent NUHEAT
- 8 – Line 2 (Black) to nVent NUHEAT

nVent NUHEAT assumes no responsibility for field wiring. Please consult a certified electrician for further instruction if needed. Wiring must be in accordance with national and local electrical codes. Wiring methods may differ for each control, please consult manufacturer's instructions for actual specifications.

North America

Tel: 1.800.778.9276
Fax: 1.604.529.4404
res.customercare@nVent.com



Our powerful portfolio of brands:

CADDY ERICO HOFFMAN RAYCHEM SCHROFF TRACER